




Shining Star

M041




M041 Instruction manual


NOTICE OF ASSEMBLE

Making tips


1. LED wiring indication:
White=Positive; Grey=Negative.
2. Use a craft blade to carefully skim over the plastic to bare the copper wire.
3. For LED wiring extension, please refer to the below steps:



Twist the copper of both LED wire and extension wire together.




Do the same on the white wire.
Remarks: Tie a knot at the end of the grey wire to differentiate the polarity.




Place the duly twist wire on the tapes provided.



Roll and wrap the wire.



Place another wire next to it.
Remarks: DO NOT contact both copper wire to avoid short circuit.



Roll and wrap it together.

Warnings

- The product is not suitable for children under 14 years old. The should be under custody of adults when playing with the product.
- There are small parts, please do not swallow them for avoiding dangerous accidents.

Tips for assembling

1. Pictures shown on the package may be slightly different from the actual product.
2. Please use the provided tracing paper for cutting purpose to achieve the best outcome.
3. Product designs and specification may be subject to change without advance notice for purpose of making improvement.
4. Testing on LED function:




Use the provide battery holder. Make sue the correct polarity.


How to assemble the battery holder




1. Material and tools needed:
- Battery holder, LED bulb, tape, screw driver and 2 piece AA size battery (not provided)




2. Use screw driver and take the lid off from the battery holder.




3. Insert the battery take notes on the polarity.



4. Connect the red wire to grey wire. Connect the black wire to white wire.



5. Wrap the exposed wire with the tapes.





6. Place the box lid and fastness with screw driver.

Product information






Piano







Bed

Cut out the material E01,E02 according to the template paper before making.



fold E01 back 1cm, attach to the bed as shown.



following above steps to make the earphone.

Bathroom







(back view)





A11-12 (attach to the back)



Carve the opening with a knife.



E02 (wash basin towel)
(back view)




cut out E08 according to the template and attach on A11-1 as shown.

Wall deco



Shower



Dumbbell




Attach F10 and F11 on E12 as above shown.

Telescope



Tent

Cut out the material E05 according to the template paper before making.



Tie the D19 with E11 as shown.


Attach E05 on D19, cut off the excess as shown.

Slipper

Cut out the material E02,E03 according to the template paper before making.



Aircraft model




Following above steps to make the aircraft model.



Scroll painting



Globe





TV wall





fold A11-19 and then cut out as shown.

tear off kraft paper of A09 as shown.







Cut out the material A10, E06 according to the template paper before making.



Attach A10 on B03 as shown.





Attach A10 on B04, and then paste E06 on back side of B04 as above shown.



Outer frame




Wall lamp





Music machine core manual guide (If you have purchased the music machine core, please fix it firstly)





Outer frame




Outer frame



attach A02,A03,A06 and A08 together as shown. the red dotted line for lamp line.






How to assemble the battery holder

Statement: the lamp wires cannot be inserted into the output socket.


- Can use 7 batteries
- Please notice the place of anode and cathode when put in the batteries
- Rechargeable batteries are not blunt electricity
- Rechargeable batteries can only be charged under adult supervision
- Rechargeable batteries should be removed from the toy before charging
- Different types of batteries cannot mix; Do not mix new batteries in use with semi-used batteries.
- Run out of battery should be removed from the toy
- The power shall not be short circuit



Installation of dust proof cover
(For updated version, the parts need to be purchased separately)



1. Tear off kraft paper of each piece of transparent cover.



2. Paste G04, G05 and G06 together to complete the dust proof cover as shown.

Photo of Dust proof cover



Attention: Please keep the instruction for future enquires after installation.